

# Temperature and pressure



Mini-Max



Proteus



Criterion



Predictor

**Mini-Max** is a remote-reading thermometer with an exterior sensor that sends data to the interior display. Mini-Max is equipped with an electronic memory that stores high and low readings until manually reset. Provides readings in Fahrenheit and Celsius, and features a temperature minder to let you mark current temperature and note any change. Includes air temperature sensor with 60' cable and AC adapter.

**Mini-Max**   **Wireless Mini-Max**



**Criterion** displays indoor reading of outdoor temperature in Fahrenheit and Celsius. This electronic remote thermometer features a user-adjustable needle at the center of the instrument that allows you to note changes in temperature. Additional sensors for air and/or water temperature can be tied to a factory installed multi-sensor switch, allowing for the display of temperature readings from different locations. Contact Maximum for more information about additional sensors. Includes air temperature sensor with 60' cable and AC adapter.

**Criterion**



**Proteus** is the finest aneroid barometer available today for under \$700. Proteus is temperature compensated and accurate to within  $\pm 0.08$  inches of mercury. The dial displays in inches of mercury (27.5"-31.5") and kilopascals (93.2-106.7), and is equipped with a resettable needle pointer used to mark changes in pressure. A cutaway dial window reveals an heirloom-quality, French barometer movement.

**Proteus**

Please specify altitude if above 3,000'.



**Predictor** displays traditional barometric nomenclature (Rain/Change/Fair) as well as measurements over a 3-inch scale of mercury (28.5"-31.5"). Accurate to  $\pm 0.16$  inches of mercury. Precision German movement is displayed behind a cutaway dial. A resettable pointer lets you track changes in barometric pressure.

**Predictor**

Please specify altitude if above 2,000'.



Wireless instruments require a Wireless Receiver, sold separately (see pg. 16).  
Add \$ for optional chrome or satin nickel case.

