

# BDT18 – Process pressure gauge 63mm

# **Product description**

Badotherm pressure gauge model BDT18 is manufactured according to the EN837-1 and is available in full stainless steel or Alloy 400 wetted parts in a stainless steel case. This pressure gauge is typically used for applications in the chemical, petro-chemical, oil & gas, power and utilities, machine building and general process industries. Safety comes first, with a blow-out feature, pressure elements made of high quality tubes. These gauges are designed to withstand the severest of operating conditions of the ambient environment and the process medium.

# **Design standard**

EN837-1

## Dial sizes, ranges & accuracy

Possibilities in ranges and accuracies are led by the dial size Accuracy class is based on dry gauges. Liquid filling can affect the accuracy.

Dial size	Ranges	Accuracy
63mm	01 to 01000 bar	1.6%

## **Mounting variation**

Not all gauges are suitable for some mounting variations. For the BDT18 series the mounting variations are below.

- type A (10) bottom connection, direct mounting
- type B (33) Lower-back connection U-bracket
- type C (11) bottom connection, surface mounting (back)
- type D (30) Lower back connection, direct mounting
- type E (32) lower back connection, panel mounting (front)

More specifically per dial size:

Dial size	Α	В	С	D	E	F
63mm	•	•	•	•	•	



### **Process connection**

Dial size	Standard thread	optionally	SW size
63mm	G 1/4 A or 1/4 " NPT	1/8"	14mm

Other thread standards such as ISO 7-1 R (BSPT), or DIN 13-1 (Metric) can be selected as well.

-> See datasheet "thread information" for specific thread details

# **Materials of construction**

	BDT18	BDT18M
Case	AISI 204 (a	optionally 316)
Bezel	AISI 304 (C	puonany 316)
Connection <sup>1</sup>	AISI 316	Alloy 400
Sensing element <sup>1</sup>	AISI 316	Alloy 400
Movement	Stainl	ess steel
Pointer	Alur	minium
Dial	Alui	IIIIIIIIIII
Window gasket		NBR
Blow out	ľ	NDK
Fill plug	NBR (HNBR	for filled gauges)
Mounting flanges	AIS	SI 304
Window	Laminated	l safety glass
1 watted materials		

<sup>\*1</sup> wetted materials



## **Pressure limitations**

The gauge are built to withstand harsh environments however the EN 837 limits the use of a pressure gauge according below table.

Dial size	Steady	Fluctuating	Short time
63mm	0.75 x FSV	0.67 x FSV	FSV
EOV /: (::11 1 - : 1 : : -			

FSV: full scale value

# **Temperature limitations**

The gauges can withstand ambient and process temperature up to a certain limit. The limitations on temperature are:

	Ambient	Medium
Dry	-40°C+60°C	-40°C+200°C
Filled	-20°C+60°C	-20°C+90°C

The variation of indication caused by the effect of temperature shall not exceed: ± 0.4% / 10K FSV

#### Window

Standard BDT18 63mm has a laminated safety window. Options such as glass, or acrylic windows are available.

## **Pointer**

Standard pointer is a fixed black painted aluminum pointer.

There are several types of pointers available:

Adjustable slotted pointer

#### Dial facing

The dial plate is made from aluminum and coated with UV resistant white coating. The black dial markings, scale, numbering, and interval is according the EN 837. Options like colored dial, customer logo, or colored segments are possible as well. Scale interval and numbering is following the EN837.

### **Limit stop**

To prevent permanent damage after overpressure, or sudden vacuum the gauge is protected by a stop pin on the dial.

## **Degree of protection**

The BDT18 has a standard degree of protection of IP65. The values are determined according the IEC/EN 60529.

# Case filling

The gauges can be filled with different kind of fill fluids. The fill fluids available are:

- BPF01 Glycerine 86%
- BPF02 Silicon
- BPF04 Foaming service
- BPF05 ECTFE inert fluid for oxygen service
- BPF06 Glycerine 99.5%

#### **Restrictor Screw**

All gauges can be executed with a restrictor of 0.8 or 0.3 orifice in AISI316.

## **Special service**

The gauges can be supplied cleaned for oxygen use. This means the gauge is assembled and tested in a special area free of oil. The gauges are individually packed in a plastic bag with marking. The symbol:



#### **Certification & Declaration**

#### Calibration

Gauges are full range calibrated as a factory standard. Optionally you can select a 5 points calibration certificate, and a 10 points calibration certificate for the 0.6% and 0.5% gauges.

Pressure Equipment Directive - 2014\_68\_EU

PED approval is given according article 3.3 and is valid for ranges >200 bar. All gauges will be marked accordingly. A declaration of conformity can be supplied.

ATEX 114 - 2014/68/EU

ATEX restrictions are explained in the IOM and in the ATEX background datasheet.


EN 10204 material certificate

A material 3.1 certificate on the wetted parts can be supplied.





# **Dimensions table**

# Type A (10)




<u>Type B (33)</u>






Dial size	d	d1	b	b2	L	h	g	SW	H	weight
63	63.8	61.7	13.0	18.5	33.5	18.0	G 1/4	14	60.5	0.2 / 0.3

# Type C (11)







Dial size	d	d1	b	L	h	K	d2	D1	g	SW	Н	weight
63	63.8	61.7	13.0	36.5	15.0	71.5	4.3	85.0	G 1/4	14	54.5	0.2 / 0.3




# Type D (30)






Dial size	d	d1	b	L	h	g	SW	H	weight	
63	63.8	61.7	13.0	33.5	18.0	G 1/4	14	60.5	0.25	

# <u>Type E (32)</u>





Dial size	d	d1	b	b2	L	h	K	D1	g	SW	Н	weight
63	63.8	61.7	13.0	17.0	33.5	18.5	73.4	85.0	G 1/4	14	60.5	0.2 / 0.3

# BDT18-SB



# **Product code 63mm**

	Code											Ī
Example	e code:	BDT18	63	Α	G14M	S363	S304	F	0	Α	B50	
Түре												
63 mm ◀	63											
Mounting*1	03											
Bottom connection - direct mounting (10) ◀	А											
Lower back connection - flush U-bracket clamp fix												
Bottom connection - surface mounting (11)	C C											
Lower back connection direct mounting (30)	D											
Lower back connection panel mount (32)	E											
Connection	_											
G 1/8" A	G18M											
1/8" NPT	N18M											
G1/4 A◀	G14M											
1/4" NPT	N14M											
TUBE & SOCKET MATERIAL	1411111											
AISI 316◀	S363											
Alloy 400	A400											
CASE/BEZEL MATERIAL	71100											
AISI 304◀	S304											
POINTER	0004											
Fixed pointer◀	F											
Adjustable slotted pointer	A											
LIQUID FILLING	А											
Dry◀	0											
BPF 01 - Glycerine filled 1,23 (86%)	1											
BPF 06 - Glycerine filled 1,26 (99,5%)	6											
BPF 02 - Silicone filled	2											
BPF 04 - Foaming service	4											
BPF 05 - Oxygen service	5											
WINDOW*2	· ·											
Acrylic (SAN) ◀	А											
Laminated glass (S1)	L											
Glass	G											
RANGE	0											
See page table 1 and table 2												
ACCURACY												
1,6 <b>◀</b>	16											
1,0	10											

<sup>◄:</sup> is the sign for the standard pressure gauge



**Tabel 1: Pressure Range code** 

bar			psi		MPa		kPa	kgf/cm2			
Code	Range	Code	Range	Code	Range	Code	Range	Code	Range		
C36	-10,6	C37	30Hg/15psi	N50	01,6	D36	-10060	E36	-10,6		
C38	-11,5	C39	30Hg/30psi	N54	02,5	D38	-100150	E38	-11,5		
C40	-13	C41	30Hg/60psi	N57	04	D40	-100300	E40	-13		
C42	-15	C44	30Hg/100psi	N58	06	D42	-100500	E42	-15		
C45	-19	C46	30Hg/150psi	N60	010	D45	-100900	E45	-19		
C50	-115	C50	30Hg/220psi	N62	016	D50	-1001500	E50	-115		
C54	-124	C53	30Hg/300psi	N65	025	D54	-1002400	E54	-124		
B01	-10	P32	010	N69	040	L01	-1000	K01	-10		
B04	-0,60	P35	015	N71	060	L04	-600	K04	-0,60		
B31	00,6	P37	030	N73	0100	L31	060	K31	00,6		
B35	01	P40	060	N76	0160	L35	0100	K35	01		
B36	01,6	P43	0100			L36	0160	K36	01,6		
B38	02,5	P46	0160			L38	0250	K38	02,5		
B40	04	P48	0200			L40	0400	K40	04		
B42	06	P51	0300			L42	0600	K42	06		
B45	010	P55	0400			L45	01000	K45	010		
B50	016	P56	0500					K50	016		
B54	025	P57	0600					K54	025		
B57	040	P58	0800					K57	040		
B58	060	P59	01000					K58	060		
B60	0100	P60	01500					K60	0100		
B62	0160	P61	02000					K62	0160		
B65	0250	P64	03000					K65	0250		
B69	0400	P66	04000					K69	0400		
B71	0600	P68	05000					K71	0600		
B73	01000	P69	06000					K73	01000		
		P72	010000								
		P73	015000								

Table 2: Secondary scale

rabio in Coconidary coars	
Dual scale option	code
PSI red	#PR
PSI black	#PB
PSI blue	#PBL
bar red	#BR
bar black	#BB
bar blue	#BBL

Add the code behind the pressure code (eg B45#PR for 0...10 bar//psi with red scale)

**Table 3: General option code** 

Table 3. General option code		
Option (start options with X_)	code	
Drag pointer	_SP	
Index pointer	_IP	
Fixed pointer on dial	_FP	
Restrictor screw 0.8mm (AISI316)	_RS8	
Restrictor screw 0.3mm (AISI316)	_RS3	
Restrictor screw 0.8mm (Alloy 400)	_RM8	
Calibrated at 0°	_C0	
Calibrated at 180°	_C180	
Cleaned for Oxygen use	_CFO	
NACE ISO 15156 (MR 01 75) (alloy 400)	_N75	
ATEX II2GDc-IM2c	_ATEX	
3.1 material certificate	_IC31	
Calibration certificate 5 points	_CC5	



PG BDT18SB-63 1st of October 2021

# **Change log**

Date	Change

## Holland - Romania - India - Thailand - Dubai - USA

To our knowledge, the information contained herein is accurate as of the date of this document. However neither Badotherm, nor its affiliates makes any warranty, express or limited, or accepts any liability in connection with this information or its use. This information is for technical skilled persons at their own discretion and risk and does not relate to the use of this product in combination with any other product. The user alone finally determines suitability of any information or material in contemplated use, the manner of use and whether any patents are infringed. This information gives typical properties only. Badotherm reserves the right to make changes to the specifications any materials without prior notice. The latest version of the datasheet can be found on www.badotherm.com.

© 2015 Badotherm, all rights reserved. Trademarks and/or other products referenced herein are either trademarks or registered trademarks of Badotherm.