

Dräger Flow Check Air Flow Indicator

The Dräger Flow Check air current indicator produces a harmless cloud of smoke that floats freely and easily, because it has the same density as ambient air. Consequently, slight air currents become visible to easily identify leaks and test the integrity of air-tight systems.



Benefits

Better room temperature and air quality

For the optimal setting of heating, ventilation and air conditioning systems, air flows have to be located accurately and precisely. Using the Flow Check air flow indicator even the slightest air movement is made visible, so the origin, direction and relative speed can easily be detected. The device produces a cloud of smoke, that floats freely and easily, because it has the same density as ambient air.

Harmless smoke

The Dräger Flow Check consists of one device for the smoke production and an ampoule containing smoke-generating fluid (an alcohol mixture that is harmless to the environment). A small heating element in the head of the instrument heats the fluid, which condenses on contact with the ambient air.

Easy to use

The ergonomically designed, hand-held instrument is light weight and offers a single button for ease of operation. Pressing the button for a few seconds creates short burts of smoke or continuous smoke by pressing and locking the button.

Services



Dräger Service

When your operation's safety equipment is backed by over 125 years of experience and supported by the same team that engineered it, you can rely on service and rental solutions that are tailored to meet your unique needs. With Dräger's safety solutions, you get complete peace of mind, budget security, and full-service support that you can count on every step of the way. That's the Dräger Service Advantage.

10070-07001

Technical Data

Operating Temperature	5 °C to 40 °C (41 °F to 104 °F)
Smoke Time per Ampoule	approx. 3 min
Operating Time per Battery Charge	approx. 20 min
Ni-Cd rechargeable Battery	7.2 V; 1.4 Ah
Charging current	700 mA
Dimensions	approx. 300 mm x 200 mm x 70 mm (11.8 in x 7.8 in x 2.8 in)
Weight	approx. 500 g (1.1 lbs.)

Ordering Information

Dräger Flow Check

Air flow indicator with one pack of 3 ampoules, battery pack and	64 00 761
charger, packaged in a rigid plastic case.	
Accessories	
Flow Check ampoules (3 ampoules and 1 nozzle)	64 00 812
Battery Charger 110 VAC	37 03 625
Battery pack	64 00 817

Notes

91 05 321 20.04-1 | HQ | PP | Subject to modifications | © 2020 Drägerwerk AG & Co. KGaA

Not all products, features, or services are for sale in all countries. Mentioned Trademarks are only registered in certain countries and not necessarily in the country in which this material is released. Go to www.draeger.com/trademarks to find the current status.

CORPORATE HEADQUARTERS

Drägerwerk AG & Co. KGaA Moislinger Allee 53-55 23558 Lübeck, Germany www.draeger.com

USA

Draeger, Inc. 7256 S. Sam Houston Parkway W., Suite 100 Houston, TX 77085 1 800 4DRAGER (1 800 437 2437)

CANADA

Draeger Safety Canada, Ltd. 2425 Skymark Ave., Unit 1 Mississauga, Ontario L4W 4Y6 1 877 DRAGER1 (1 877 372 4371)

Locate your Regional Sales Representative at: www.draeger.com/contact

