


# Electrical Connector Terminal Wiring and Pinout

## 4-Pin Bayonet

Environmental Rating IP67, Ordering Code -2


Pin No.	4-20 mA Output	Voltage Output
A	V+	V+
B	V-	Common
C		Output
D		



## DIN EN 175301-803 Form C

Environmental Rating IP65, Ordering Code -7, -70


Pin No.	4-20 mA Output	Voltage Output
1	V+	V+
2	V-	Common
3		Output
4		



## M12x1 (4-Pin)

Environmental Rating IP67, Ordering Code -25


Pin No.	4-20 mA Output	Voltage Output
1	V+	V+
2		
3	V-	Common
4		Output



## Integral Cable

Environmental Rating IP68: -36  
(Gauge reference devices <400 psi are IP67)  
Environmental Rating IP65: -17, -18


Cable Color	4-20 mA Output	Voltage Output
Brown	V+	V+
Blue	V-	Common
Black		Output
Drain (Bare)	Shield	Shield



## 6-Pin Bayonet

Environmental Rating IP67, Ordering Code -3


Pin No.	4-20 mA Output	Voltage Output
A	V+	V+
B	V-	Common
C		Output
D		
E		
F		



## DIN EN 175301-803 Form A

Environmental Rating IP65, Ordering Code -8, -14, -80


Pin No.	4-20 mA Output	Voltage Output
1	V+	V+
2	V-	Common
3		Output
4		



## 3-Pin Packard

Environmental Rating IP67, Ordering Code -34


Pin No.	4-20 mA Output	Voltage Output
A	V-	Common
B	V+	V+
C		Output



## Deutsch Integral 3-Pin (DT04-3P)

Environmental Rating IP67, Ordering Code -46


Pin No.	4-20 mA Output	Voltage Output
A	V+	V+
B	V-	Common
C		Output



## Deutsch Integral 4-Pin (DT04-4P)

Environmental Rating IP67, Ordering Code -21


Pin No.	4-20 mA Output	Voltage Output
1	V-	Common
2	V+	V+
3		
4		Output



## Deutsch Integral 2-Pin (DT04-2P)


Environmental Rating IP67, Ordering Code -66

Pin No.	4-20 mA Output
1	V+
2	V-




## Power Supply Requirements And Ratings

### 4 mA to 20 mA Output



### 3-Wire Voltage Output



**V+ =** Supply voltage  
**V- =** 4 mA to 20 mA signal  
**Output =** Voltage Output signal  
**Common =** Supply voltage return/ground

### Load Limitations

4 mA to 20 mA output only

**V<sub>min</sub> =** 10V + (.020 x RL)

**RL =** RS + RW

**RL =** Loop resistance (ohms)

**RS =** Sense resistance (ohms)

**RW =** Wire resistance (ohms)

Output Signal	Min Supply	Max Supply	Max Current Consumption
4 mA to 20 mA	12 Vdc	36 Vdc	25 mA
0 Vdc to 5 Vdc	12 Vdc	36 Vdc	8 mA
1 Vdc to 5 Vdc	12 Vdc	36 Vdc	8 mA
0 Vdc to 10 Vdc	12 Vdc	36 Vdc	8 mA
0.5 to 4.5 Vdc	12 Vdc	36 Vdc	8 mA
0.5 to 4.5 Vdc ratiometric	4.5 Vdc	5.5 Vdc	8 mA

## Technical Specifications Related To Safety

See product label for specific product input (voltage), output (voltage or current), and pressure ranges.

**Temperature Ranges**  
 Compensated -4 °F to 185°F (-20 °C to 85 °C)  
 Media -22 °F to 221 °F (-30 °C to 105 °C)  
 Ambient -4 °F to 185°F (-20 °C to 85 °C)  
 Storage -40 °F to 257 °F (-40 °C to 125 °C)

**Compensated Temperature Error** 0.15% of span / 10 K

**Proof Pressure**  
 < 7500 psi: 2 times full scale  
 7500 - 10,000 psi: 1.5 times full scale  
 >10,000 psi: 1.2 times full scale

**Burst Pressure**  
 < 7500 psi: 3 times full scale  
 7500 - 10,000 psi: 2 times full scale  
 >10,000 psi: 1.5 times full scale

**Ingress Protection Ratings**  
 IP65 to IP68 depending on electrical connection (Refer to Electrical Connector Terminal Wiring and Pinout)

**Shock** 200 g's according to IEC 60068-2-27

**Vibration** 20 g's according to IEC 60068-2-6

**Uncertainty** ±0.29% of span, including non-linearity best fit straight line, hysteresis, and non-repeatability per IEC 61298-2 at reference conditions

- Non-Linearity 0.25%
- Hysteresis 0.10%
- Non-repeatability 0.10%

$$Uncertainty = \sqrt{(Non-linearity)^2 + (Hysteresis)^2 + (Non-repeatability)^2}$$



## User Manual

# PT30 Series High Performance Fixed Range Transmitter



### WARNING

Please read the entire user manual for safe use of product.

**NOTE:** If NOSHOK PT30 Series High Performance Fixed Range pressure transmitters are used in a manner not specified in this manual, the protection provided by the equipment may be impaired.

**NOTE:** The safety of the system is the responsibility of the assembler of the system. See [www.noshok.com](http://www.noshok.com) for further product detail and documentation.

### General Description

NOSHOK PT30 pressure transmitters are high performance instruments intended for use in industrial applications where the process media is compatible with the 316 Stainless Steel wetted parts and system temperatures and pressure are within the limits specified herein.

### Installation

NOSHOK PT30 pressure transmitters require no special mounting hardware and can be mounted in any orientation with negligible position error.

Although the units can withstand considerable vibration without damage or significant output effects, it is always good practice to mount the transmitter where there is minimum vibration. Refer to product specification for allowable shock and vibration conditions.

For units with NPT type pressure fittings apply sealing tape or an equivalent sealant to the threads before installing.

When installing or removing the unit apply a wrench to the hex wrench flats, located above the pressure fitting. A 24 mm wrench can be used on the wrench flats of the hex.

Mating connection cable assemblies are available as an accessory part from NOSHOK. For instruments carrying the UL approval, these mating connection cables may be required. Refer to Electrical Connector Terminal Wiring and Pinout for additional detail.

A pressure snubber may be installed to eliminate damaging hammer effects. Water and conventional cleaning detergents are acceptable cleaning agents. Cleaning with unsuitable cleaning agents may damage the instrument or the product label. Do not use any aggressive chemical agents or abrasive cloths or sponges.

Transmitter should be electrically common with earth via the process connection.

- Refer to Power Supply Requirements and Ratings.
- Refer to Electrical Connector Terminal Wiring and Pinout.
- Refer to product technical specification for allowable minimum and maximum temperature and pressure conditions.

### General Operation

Pressure spikes in excess of the rated overpressure capability of the transmitter may cause irreversible electrical and/or mechanical damage to the pressure measuring and containing elements. Fluid hammer and surges can destroy any pressure transmitter and must always be avoided.

### Maintenance and Service

NOSHOK PT30 pressure transmitters are precisely calibrated, and temperature compensated at the factory to ensure long and stable performance.

There are no field accessible adjustments. This product is maintenance-free. Repairs should only be carried out by the manufacturer.

### Additional Notes

Any electrical device may be susceptible to damage when exposed to static electrical charges. To avoid damage to the transmitter, observe the following:

- The circuitry of the NOSHOK PT30 pressure transmitters is designed to minimize the effect of electromagnetic and radio frequency interference. To minimize susceptibility to noise, avoid running the termination wiring in a conduit which contains high current AC power cables.
- Where possible avoid running the termination wiring near inductive equipment.

**NOTE:** The shield and drain wire in the cable (if supplied) is not connected to the transmitter body and is not a suitable ground.



1010 West Bagley Road • Berea, Ohio 44017  
 440-243-0888 • Fax 440-243-3472  
[noshok@noshok.com](mailto:noshok@noshok.com) • [www.noshok.com](http://www.noshok.com)

PT30UM-23